

# COLUMN CLAMPS

## FORMWORK FOR CONCRETE COLUMNS



Formwork Direct Column Clamps are quickly adjusted and secured to ensure positive clamping of steel and timber formwork for Concrete Columns.

Formwork Direct Column Clamps are designed to clamp the formwork tightly together at the corners. Except on small column cross sections they cannot alone be expected to support the plywood form face against the pressure of the concrete. Larger columns will require formwork designed to avoid bending into the column clamps.

Column Clamps are perfect for saving time, wastage and labour costs and are designed with longevity in mind.

**FD-CCL-0000-0001**

# COLUMN CLAMPS

## FORMWORK FOR CONCRETE COLUMNS

Product Detail	Information
Sizes	1   2   3
Arm Length	710   1065   1475 mm
Arm Adjustment	228-546   330-880   596-1270 mm
Benefits	<ul style="list-style-type: none"><li>• Better than timber: Saves time, labour and wastage.</li><li>• Designed for long life</li><li>• 3 sizes of arm are interchangeable and suit both square and rectangular sections.</li><li>• Flexible, galvanized steel wires avoid broken chains and lost wedges.</li></ul>

### Advantages



Designed for long life.



3 sizes of arm are interchangeable and suit both square and rectangular sections.



Flexible, galvanized steel wires avoid broken chains and lost wedges.